



Acer	N14	Aspire 2000WLCI, 2000WLMi Travelmate 200, 505 to 508 series, 600 series, 8000 series, C110Ti, C300
Apple	N16	iBook (Firewire), (Vintage—original), 12.1 in >500MHz, 14.1 in >500MHz, G3 PowerBook G3, 2000 Wall Street Kanga, G3 Lombard, G3 series, Lombard Bronze
	N23	iBook G4 (12 inch Display), G4 (14 inch display), PowerBook G4 12 inch, G4 15 inch, G4 17 inch, Titanium G4
Averatec	N3	3100 series, 3200 series, 5100 series
Compaq	N3	Evo N115 series, N160 series, N180 series Presario 1000 series, 1200 series, 1400 series, 1600 Series, 1700 Series, 1800 Series, 2700 Series, 700 Series, 800 series
	N8	Armada 100, 1100, 1120, 1125, 1130, 4100 series, 4200 series LTE 5000, LTE 5080, LTE 5100, LTE 5150, LTE 5180, LTE 5200, LTE 5230, LTE 5250, LTE 5280, LTE 5300, LTE 5380, LTE 5400, LTE 5480, LTE 6000
	N9	Armada E500, E500s, E700, M300, M700, V300 Evo N110 series, N150 series, N200 series, N400c, N410c, N600c, N610c, N620c, N800c, N800v nc4000, nc6000, nc8000, nw8000 Presario 2200 Series, 2800 Series, 2900 series, 300 Series, M2000 series, V2000 series, X1000 Series, X1300 series, X1400 series Prosignia 150, 170, 190 Tablet TC-1000, TC-1100
Dell	N11	Latitude LT
	N3	Inspiron 200N, 250N, 3000, 3000 D, 3000 M2335T/XT, 3200, 3500, 7000, 7000 D400LT
	N4	Latitude XP Series: 100cx, 4100C, 4100D, 4100T, 450c, 450x, 475c, 475D



Dell	N5	Inspiron 2500 12.1 inch disp, 2500 14 in display, 2500 15 in display, 2600, 2650, 3700, 3800, 4000, 4100, 4150, 5000, 5000e, 7500, 8000, 8100 14 inch display, 8100 15 in display Latitude C400, C410, C500, C510, C540, C600, C610, C800, CP Series, CPI series, CPT Series, CPX Series, CS/CSx Series, LM, X200, XPI Series
E-machine	N3	Eslate 400K, 450K
Fujitsu-Siemens	N15	FMV-BIBLO LOOX S80B, S80B/W, S80C, S80C/W, T50E, T50E/W, T70E, T93B, T93B/W, T93C, T93C/W FMV-BIBLO FLX2H, MG12B, MG12B/C, MG12B/M, MG12C, MG12C/M, MG12D, MG13D, MG17D/A, MG50E, MG55E, MG70E, MG70E/ST, MG75E, MR16B, NB14B, NB14B/R, NB15B, NB15B/S, NB15B/T, NB16B, NB16B/M, NB16C, NB16C/ST, NB16C/T, NB16C/V, NB16CA, NB16CR, NB18B, NB18C, NB18C/T, NB18D, NB18D/D, NB18D/F, NB18D/L, NB18D/V, NB19D, NB19D/D, NB70E, NB70E/T, NH24C, NH24D, NH26C, NH28D, NH50E, NH70E, NH90E/T, NU, RS18D, RS18D/D, RS18D/ST, RS18D/T, RS50E/T, RS55E/T Lifebook 200 Series, 400 Series, 500 Series, 600 Series, 700 Series, 900 Series, B112, B142, B2, B2130, B2131, B2545, B2562, B2562 w/high cap main battery, B2562 w/main battery, B2566, B2566 w/high cap main battery, B2566 w/main battery, B2610, B2620, B2620, C340, C350, C352, C353, C360, C4120, C4235, C5130, C5235, C6177, C6320, C6330, C6525, C6535, C6537, C6547, C6556, C6557, C6577, C6581, C6591, C6611, C6631, C6651 14.1 in. display, C6651 15 in. display, C7631, C7651 14 in. display, C7651 15 in. display, C7661 14 in. display, C7661 15 in. display, Celsius Mobile H, E2010, E330, E340, E342, E350, E351, E360, E362, E370, E380, E5140, E5320, E5520, E6150, E6520, E6530, E6540, E6541, E6550, E6555, E6556, E6557, E6570, E6571, E6575, E6595, L440, L470, S2010, S4510, S4542, S5582, S6010, S6110, S6120, S6120D, T3010D LifeBook Stylistic 3400, 3500, LT C-500, LT P-600, ST4110, ST4110P, ST4120, ST4120P LifeBook ST4121



Fujitsu-Siemens	N3	LifeBook A1010, A4170, A4177, A4178, A4187, A4190, Amilo L, C2101, C2110, C2111, C2210, E4010, E4010D, E6624, E6634, E6644, E6654, E6664, E7010, E7110, P1000, P1032, P1035, P1120, P2000, P2040, P2046, P2110, P2120, P5010, P5010D
Gateway	N12	200X, 200XL, Solo 200ARC Solo 200ARC
	N3	400SD4, 450ROG, 450SX4, 600YG2, 600YGR, M1200, M305, M305X, M500 Solo 1100, 1150, 1150 CL, 1150 CS, 1200, 1400, 1400LS, 1400SE, 1450 LS, 1450 SE, 200, 2000, 2100 series, 2150 series, 2200 series, 2300 series, 2500 Series, 2550 series, 3100 Series, 3150 Series, 4520GZ, 4525GZ, 5100 Series, 5150 Series, 5300 Series, 5350 Series, 600 series, 9100 Series, 9150 series, 9300 Series, 9500, 9550 series Tablets Tablet PC, Tablet PC Deluxe
HP	N3	Omnibook 2000, 2100, 2103, 2105, 300, 3000, 3100, 3101, 4100, 4101, 4103, 4105, 4150, 425, 430, 500, 5000, 510, 530, 5500, 5700, 6000 14 in display, 6000 15 in display, 600c, 600ct, 6100 14 in display, 6100 15 in display, 7100, 7103, 7150, 900, 900b, vt6200, XE, XE2, XE3 14 in display, XE3 15 in display, xe4000, xe4100, xe4200, xe4400, xe4500, xt1000, xt1500, xt6050, xt6200 Series 14 inch, xt6200 Series 15 inch, ZE, ZE2, ZE3 Pavilion 2105, 3000, 3100, 3101, 4100, 4101, 4103, 4105, 5159, 6000, 6100, 7100, N3000, N3100, N3110, N3150, N3190, N3200, N3210, N3215, N3220, N3250, N3270, N3290, N3295, N3300, N3310, N3330, N3350, N3370, N3390, N3400, N3402, N3410, N3438, N3478, N3490, N5100, N5124, N5125, N5130, N5135, N5140, N5150, N5159, N5170, N5190, N5195, N5210, N5221, N5240, N5241, N5250, N5261, N5270, N5271, N5290, N5295, N5310, N5311, N5340, N5341, N5350, N5351, N5371, N5381, N5390, N5400, N5402, N5412, N5415, N5420, N5421, N5422, N5425, N5430, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N6000, N6100, N6190, N6195, N6300, N6395, N6396, N6397, N6398, N6399, N6400, N6401, N6402, N6403



HP	N3	<p>Pavilion N6404, N6490, xf125, xf145, xf235, xf255, xf315, xf325, xf328, xf335, xh136, XH156, xh176, xh215, xh216, xh226, xh355, xh365, xh455, xh485, xh535, xh545, xh555, xH575, xh675, xt115, xt118, xt125, xt128, xt155, xt178, xt183, xt188, xt236, xt276, xt345, xt375, xt395, xt412, xt537, xt5377, xt545, xt555, xt565, xt575, xt585, xt595, xu155, xt133, xz148, xz163, xz168, xz185, xz275, xz295, xz335, xz355, xz815, zd7000 series, ze1000, ze1100, ze110, ze1115, ze1145, ze1200, ze1201, ze1202, ze1210, ze1230, ze1250, ze1260, ze4100 series, ze4200 series, ze4300 series, zt1100 series, zt1200 series, zt1331, zt3340us, zu1155, zu1175</p>
	N9	<p>Pavilion dv1000 series, ze4900 series, zt3000 series, zt3100 series, zt3200 series, zt3300 series</p>
IBM	N2	<p>ThinkPad 240, 240X, 290, 365, 365XD, 380, 380D, 380E, 380ED, 380XD, 380Z, 385, 385D, 385ED, 385XD, 390, 390E, 390X, 550, 560, 560E, 560X, 560Z, 570, 600, 600D, 600X, 660, 701, 770, 770E, 770ED, 770X, 770Z, A20, A20, A21, A20M, A20P, A21, A21E, A21M, A21P, A22, A22M, A31, E530, i Series 1200 models, i Series 1300 models, i Series 1400-2621 models, i Series 1500-2621 models, i Series 1700 models, R30, R31, R32, R40, R40e, R50, R50p, S, T20, T21, T22, T23, T40, T41, TransNote, X20, X21, X22, X31, X40</p> <p>Transnote 2625</p>
	N8	<p>ThinkPad 310, 310D, 310E, 310ED, 315, i Series 1400-2611 models, i Series 1500-2611 models</p>
NEC	N3	<p>LaVie C LC500/4D, LC700/4D, LC700/6D, LC700/7D, LC900/4D, LC900/7D, LC950/4D, PC-LC3001A, PC-LC3002D, PC-LC5001D, PC-LC5002D, PC-LC5003D, PC-LC5004D, PC-LC5005D, PC-LC5503DW, PC-LC7001D, PC-LC7003D, PC-LC7004D, PC-LC7005D, PC-LC9001D, PC-LC9002D, PC-LC9003E, PC-LC9004D, PC-LC9005D, PC-LC950/4D, PC-LC9503E, PC-LC9504E</p> <p>LaVie F LF550/4D, PC-LF5504D, PC-LF5505D, PC-LF7507D</p>



NEC

N3

LaVie G PC-LG10JLFEA, PC-LG10JLFEB, PC-LG10JLFJA, PC-LG10JLFB, PC-LG10JSFEA,
 PC-LG10NRXEA, PC-LG10NRXJA, PC-LG10RRXEB, PC-LG10RRXJB, PC-LG11NRXEB,
 PC-LG11NRXJB, PC-LG14NFXEC, PC-LG14NRXEC, PC-LG14NRXJC, PC-LG14SSFEB,
 PC-LG14SSFJB, PC-LG14SSGEB, PC-LG14SSGJB, PC-LG15HLXEC, PC-LG15HLXJC,
 PC-LG15SEFEC, PC-LG15SEFJC, PC-LG15SFFEC, PC-LG15SFFJC, PC-LG15SSGEC,
 PC-LG15SSGJC, PC-LG16HEVED, PC-LG16HEVJD, PC-LG16HLFED, PC-LG16HLFJD,
 PC-LG16HLVED, PC-LG16HLVJD, PC-LG16NRXED, PC-LG16NRXJD, PC-LG16SLFED,
 PC-LG16SLFJD, PC-LG16SLVED, PC-LG16SLVJD, PC-LG16SSUJB, PC-LG18SEFEC,
 PC-LG18SEFJC, PC-LG18SEVED, PC-LG18SEVJD, PC-LG18SSFED, PC-LG18SFFJD,
 PC-LG18SSGED, PC-LG18SSGJD, PC-LG18SSUEC, PC-LG18SSUJB, PC-LG18SSUJC,
 PC-LG19NRXEC, PC-LG19NRXJC, PC-LG20NRXED, PC-LG20NRXJD, PC-LG20SEGEC,
 PC-LG20SEGED, PC-LG20SEGJC, PC-LG20SEGJD, PC-LG20SSUEC, PC-LG20SSUED,
 PC-LG20SSUJC, PC-LG20SSUJD, PC-LG90RRXEA, PC-LG90RRXJA

LaVie J LJ500/4D, LJ700/4F, LJ700/7E

LaVie L LL300/4F, LL500/4D, LL500/6D, LL530/7A, LL550/4D, LL550/6D, LL550/7D, LL700/4D,
 LL700/6D, LL700/7D, LL750/4D, LL750/7D, LL770/6DT, LL770/7DT, LL900/6D, LL900/7D,
 LL950/6D, PC-LL3001A, PC-LL3004F, PC-LL5001D, PC-LL5002D, PC-LL5003D,
 PC-LL5004D, PC-LL5005D, PC-LL5503D, PC-LL5504D, PC-LL5505D, PC-LL7001D,
 PC-LL7002D, PC-LL7003D, PC-LL7004D, PC-LL7005D, PC-LL7305D, PC-LL7502D,
 PC-LL7503D, PC-LL7504DW, PC-LL9001D, PC-LL9005D, PC-LL9305D, PC-LL9507D

LaVie M LM500/4E, LM500/7D, LM700/7E

LaVie ME LE500/7D

LaVie N LN500/6D, LN500/7D, LN570/7DT

LaVie Pro PC-LH3002A, PC-LH3003F, PC-LH7002D, PC-LH7003E

LaVie T LT500/4D, LT700/4D, PC-LT3005D, PC-LT5004D, PC-LT5005D, PC-LT7004D

Pocket Gear MC/PG5000, MC/PG7000



NEC	N3	ReadyNotebook 220T, 230T, 330T, 340T, 360T, 440T Versa 2400, 2405, 2405/CD, 2500, 2500CD, 2505, 2530, 4000, 4050, 4080H, 4200, 4230, 5000, 5060, 5060X, 5080, 5080X, 550D, C140, C150, C160, E120, E600, FM320, FM500, FP520, FS800, IGO3000, IGO5000, IGO6000, L320, M300, M320, M3210, M500, P440, P520, P600, P700, Premium, S800, T400, T400S820, VX VersaNote VersaPro NX LaVie NX LW23C/52, LW23D, LW26H, LW30H, LW33H
	N4	LaVie G PC-LG16NFXED
	N5	Versa 2000, 2000/c/d, 2000C, 2000D, 6050MH, 6050MT, 6050MX, 6200 series, 6200MX, 6200NT, 6220, 6230, 6260
Panasonic	N15	ToughBook 27 or CF27, 28 or CF28, 34 or CF34, 37 or CF37, 47 or CF47, 71 or CF71, CF01, CF11, CF17, CF170, CF25, CF270, CF33, CF35, CF370, CF380, CF41, CF45, CF61, CF62, CF63, CF-M34, CF-V25
	N2	ToughBook 18 or CF18, R1 or CF-R1, T1 or CF-T1, T2 or CF-T2, W2
Sharp	N11	Actius A110, A150, A250, A280, A290 Actius UltraLite PC-3010, PC-3020, PC-3030, PC-3040, PC-3050, PC-3060 PC3150
Sony	N15	Picturebook CiX VAIO CIMHP, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, S150, S150P, S260, S260P, S360, S360P, SR series, SRX series, T140P/L, T150P/L, T160P/L, T250P/L, T270P/L, TR1A series, TR2A series, TR3A series, V505 series, VX71P, Z1 series



Texas Instruments	N3	Extensa 350, 365, 390, 550, 560, 570, 900
Toshiba	N1	Portege 300CT, 3010, 3120, 320CT, 3490CDT, 3490CT, 3500 Tablet, 3505 Tablet, 610CT, 620CT, 650CT, 660 series, 7000CT, 7010CT, 7020CT, 7030 CT, 7140CT, 7200 CT, 7200CTe, 7220Cte, M100, M200, R100 Satellite 1000, 1005, 1100, 1200, 1500, 1555CDS, 1605CDS, 1615, 1625CDT, 1675CDS, 1695CDT, 1715XCDS, 1730, 1735, 1750, 1755, 2000, 200CDS, 2060, 2060CDS, 2065, 2065CDS, 2095, 210, 2100, 2100CDS, 2100CDT, 2100CDX, 2105, 210CDT, 2115CDS, 2140XCDS, 2180CDT, 2200, 220CDS, 2210, 2210CDT, 2210XCDS, 225, 2250, 230, 230CDS, 230CX, 235CDS, 250, 300 Series, 3000, 3005, 305 Series, 310 series, 315 series, 320 Series, 325 Series, 330 Series, 335 Series, 3400, 3600, 4600, 4700, 4800, 4850 Satellite Pro 4200, 430, 440, 440CDT, 440CDX, 440CS, 440CT, 445CDT, 445CDX, 460, 4600, 460CDT, 460CDX, 465CDT, 465CDX, 470, 470CDT, 480, 490, 490CDT, 490X, 490XCDDT, M10, M15 T1900C, T1900S, T200, T2400, T4500, T4700, T4800, T4850, T4900 Tecra 510, 520CDT, 530, 550CDT, 700, 700CDT, 700CS, 700CT, 710, 710CDT, 720, 720CDT, 730, 730CDT, 730XCDDT, 740, 740CDT, 750, 750CDM, 750CDT, 750DVD, 780
Winbook	N3	Winbook J1, N, Si series, S12, X1, X2, X4, XL, XL2, XLi, XP, XP5, Z
	N8	Winbook FX, XP5 PRO



AMW	D4	M270, M271, M280, M281, M520, M530
Apex	D4	PD-10, PD-100, PD-510
	D9	DVD-PD650
Audiovox	D4	D1500, D1510, D1530, D1680, D1700, D1730, D1800, D1830, VBP50
Initial	D4	DVD-5820, DVD-680P, DVD-800P, DVD-9510, IDM1731, IDM1810, IDM830, IDM9530, IDM9820
Mintek	D4	MDP-1010, MDP-1700, MDP-1710, MDP-1720, MDP-1770, MDP-1810, MDP-5510, MDP-5830, MDP-5860, MDP-5861
Samsung	D2	DVD-L100, DVD-L200, DVD-L300



Dell	J1	DJ
Apple	J3	iPod



Nintendo	G1	Gameboy Advance SP, Gameboy Advance DS
----------	----	--



Audiovox	M3	CDM-8400, CDM-8400, CDM-8450, CDM-8900, CDM-9900, CDM-9950, PDM8920
Handspring	M12	90270, 300, 600, Treo180
Kyocera	M3	1100, 2100, 2200, 2300, 2325, 3000, 3200, 3225, 3250, 7100, Blade, K110, K112, KE413, KE413C, KE414, KE414C, KE423, KE423C, KE424, KE424C, KE433, KE433C, KX414, KX424, KX433, Phantom, QCP-2027, QCP-2035, QCP-2035A
LG	M8	1010, 3100, 5250, 5350, 4NE1, VX1, VX10, VX2000
Moto Nextel	M9	i205, i305, i530, i730, i733, i830, i860
Motorola	M1	A630, A830, A835, A845, C331t, C332, C333, C343, C343a, C353t, C388, E310, E380, E398, i30sx, i355, i50sx, i55sr, i55sx, i58sr, i80s, i85s, i88s, i90c, i90c SE, i95cl, MPX220, T720, T722, T722l, T725, T730, T730c, T731, Timeport 270c, Timeport 280, V 120 series, V200, V260, V262, V265, V300, V400, V500, V525, V547, V551, V555, V60 series, V600, V620, V66, V66G, V70 series, V710, V80, V810
	M3	G520
Nextel	M1	i30sx, i355, i50sx, i55sr, i55sx, i58sr, i80s, i85s, i88s, i90c, i90c se, i95cl, lm1000
	M3	1500, 1700, i500, i550, i700
Nokia	M2	252, 282, 640, 650, 1100, 1200 series, 2200 series, 3100 series, 3200 series, 3300 series, 3400 series, 3500 series, 3600 series, 5100 series, 5200 series, 5300 series, 5500 series, 6000 series, 6100 series, 6200 series, 6300 series, 6500 series, 6600 series, 6800 series, 7100 series, 7200 series, 7600 series, 8100 series, 8200 series, 8300 series, 8800 series, 8900 series, 9100 series, 9200 series, N-Gage
RIM Blackberry	M15	Mini USB



Samsung	M13	i300, i330, i500, i600, i700
	M3	A460, A500, A600, A620, A660, A680, N240, N270 Matrix, N400, VGA1000, VI660
	M5	A310, A530, A610, A650, A670, A790, C225, D410, D415, E105, E315, E316, E317, E700, E715, N150, N370, N625, N626, N635, P100, P107, R225, R225M, S200, S300, S307, SGH-V200, V200, V205, V206, X105, X425, X426, X427
Sanyo	M3	5300, 5400, 5500, 8200, RL2000, RL-2500, RL-4920, SCP-7300, SCP-8100, VGA1000, VM4500
Siemens	M10	A55, A56, A60, C55, C56, C60, C62, M55, MC60, S55, S56, SL55, SX1
Sony Ericsson	M4	A2218Z, K500, K700i, P800, P802, P900, P910, R300D, R300LX, R300SC, R300Z, R380, R520M, R520MC, T100, T106, T200, T202, T206, T20E, T20EC, T20S, T226, T237, T28, T28-WORLD, T29C, T29S, T300, T306, T310, T312, T316, T39, T60, T600, T60d, T61, T610, T616, T61c, T612, T62, T630, T637, T66, T68, T68i, Z200, Z600
Dell	P4	X3, X5
HP	P3	1900, 1910, 1935, iPaq h2215
Palm	P1	i705, m125, m130, m500, m505, m515, Tungsten T3, Zire 71
Sony	P2	TJ25